

INDICI DI MASSIMA SUL QUADRANTE serie : IN

Maximum pressure limit pointers on the dial series : IN

REGOLABILI MANUALMENTE
MANUALLY ADJUSTABLE

Gli indici serie IN vengono applicati sul quadrante del manometro e servono per delimitare un limite massimo di pressione. Essi possono essere posizionati manualmente dall'utente sul punto della scala di maggior interesse.

The pointers series IN are put on the dial and needs to delimit a maximum pressure limit. They can be manually positioned by the user on the point's range of major interested.



INDICI SUL TRASPARENTE serie : INR

Pointers on the window series : INR

REGOLABILI MANUALMENTE DALL'ESTERNO
MANUALLY OUTSIDE ADJUSTABLE



Gli indici serie INR vengono applicati sul trasparente del manometro e servono per visualizzare la pressione massima o minima che ha raggiunto il manometro.

VERSIONI :

- di massima (vedere foto) ;
- di minima ;
- di minima / massima (2 indici).

The pointers series INR are put on the gauge's window and needs to show the maximum or minimum pressure reached by the gauge.

VERSIONS :

- for maximum (see the picture) ;
- for minimum ;
- for minimum / maximum (2 pointers).



Automazioni Misure & Controlli S.r.l.
Via Pietro L'Eremita, 3 - 00162 - Roma (Italy)
Tel. : +39.06.44260668 / +39.06.44202185
Fax : +39.0623328444
Mail : info@amecroma.com
Web : www.amecroma.com
Web : www.imanometri.com